



Don the short inner sleeve on clean socket.



Trim inner sleeve leaving minumun 1" of material above the socket ears



Don outer sleeve so that the distal edge is in line with edge of inner sleeve.

## How to trim down the inner sleeve



Make sure the shiny strip of silicone of the outer sleeve is touching the inner sleeve's shiny silicone strip.



Roll up outer sleeve for secure, durable suspension



Eclipse provides superb comfort and flexibility for patients

