

Elbows

E-400 Elbow Sub Assemblies

HOSMER

- | | |
|--------------|--|
| 62243 | Internal Assembly, E-400 and E-400HD |
| 62245 | Internal Assembly, E-400A and E-400HD-A |
| | <i>Includes:</i> |
| **AA. | 62242 Internal Cage Assembly for E-400 and E-400HD |
| | 62246 Internal Cage Assembly for E-400A and E-400HD-A |
| BB. | 50677 Base for E-400 and E-400HD |
| | 60661 Base for E-400A and E-400HD-A |
| CC. | 50679 Screw for E-400, E-400A, E-400HD-A and E-400HD (3 required) |
| DD. | 50680 Bolt for E-400, E-400A, E-400HD-A and E-400HD |
| EE. | 50715 Locking Bar Spring for E-400, E-400A, E-400HD-A and E-400HD |
| | 50744 Cable Guide for E-400A and E-400HD-A only (not shown) |

- 50748** Yoke Assembly
Includes:
- | | | |
|-------------|--------------|--------------------------|
| ZZ. | 50671 | Yoke |
| AAA. | 50675 | Nut |
| BBB. | 50674 | Bumper |
| CCC. | 50758 | Yoke Cover, <i>Right</i> |
| | 50773 | Yoke Cover, <i>Left</i> |
| DDD. | 50761 | Screw |

- 60143 Yoke Assembly, *E-400 XHD*
60664 Yoke Assembly, *Power Bow*

- | | | |
|--------------|---|---|
| 62242 | Internal Cage Assembly, <i>E-400 and E-400HD</i> | |
| 62246 | Internal Cage Assembly, <i>E-400A and E-400HD-A</i> | |
| 62248 | Internal Cage Assembly, <i>E-400XHD and Power-Bow</i>
<i>Includes:</i> | |
| FF. | 62246 | Cage for E-400 and E-400HD |
| | 62242 | Cage for E-400A and E-400HD-A |
| | 62239 | Cage for E-400XHD and Power-Bow |
| GG. | 50684 | Cam Bearing |
| HH. | 50831 | Screw (2 required) |
| II. | 50687 | Cam for E-400, E-400A, E-400HD,
E-400HD-A, E-400HD |
| | 60079 | Cam for E-400XHD and Power-Bow |
| JJ. | 50689 | Spring |
| KK. | 50701 | Washer |
| LL. | 50160 | Retaining Ring |
| ** MM. | 50709 | Ratchet Assembly |
| NN. | 50714 | Locking Bar |
| OO. | 50813 | Case Pin |
| PP. | 50713 | Cable Pin |
| ** QQ. | 55561 | Lever Assembly |
| RR. | 50746 | Lever Swivel |

