

Size: W5

Length: **8.38**" | 213mm Width: **1.77**" | 45mm

- 1. Place heel against wall.
- 2. Measure length from wall to the tip of your big toe.
- 3. Choose the insole that fits the length of your foot. If the length of your foot is between sizes, choose a size down.





Size: W6

Length: **8.77**" | 223mm Width: **1.85**" | 47mm

- 1. Place heel against wall.
- 2. Measure length from wall to the tip of your big toe.
- 3. Choose the insole that fits the length of your foot. If the length of your foot is between sizes, choose a size down.





Size: W7/M6

Length: **9.17**" | 233mm Width: **1.88**" | 48mm

- 1. Place heel against wall.
- 2. Measure length from wall to the tip of your big toe.
- 3. Choose the insole that fits the length of your foot. If the length of your foot is between sizes, choose a size down.





Size: W8/M7

Length: **9.56**" | 243mm Width: **1.96**" | 50mm

- 1. Place heel against wall.
- 2. Measure length from wall to the tip of your big toe.
- 3. Choose the insole that fits the length of your foot. If the length of your foot is between sizes, choose a size down.





Size: W9/M8

Length: **9.96**" | 253mm Width: **2.04**" | 52mm

- 1. Place heel against wall.
- 2. Measure length from wall to the tip of your big toe.
- 3. Choose the insole that fits the length of your foot. If the length of your foot is between sizes, choose a size down.






Size: W10/M9

Length: **10.35**" | 263mm Width: **2.12**" | 54mm

- 1. Place heel against wall.
- 2. Measure length from wall to the tip of your big toe.
- 3. Choose the insole that fits the length of your foot. If the length of your foot is between sizes, choose a size down.





Size: W11/M10

Length: **10.74**" | 273mm Width: **2.16**" | 55mm

- 1. Place heel against wall.
- 2. Measure length from wall to the tip of your big toe.
- 3. Choose the insole that fits the length of your foot. If the length of your foot is between sizes, choose a size down.






Size: W12/M11

Length: **11.14**" | 283mm Width: **2.20**" | 56mm

- 1. Place heel against wall.
- 2. Measure length from wall to the tip of your big toe.
- 3. Choose the insole that fits the length of your foot. If the length of your foot is between sizes, choose a size down.





Size: W12/M11

Length: **11.14**" | 283mm Width: **2.20**" | 56mm

- 1. Place heel against wall.
- 2. Measure length from wall to the tip of your big toe.
- 3. Choose the insole that fits the length of your foot. If the length of your foot is between sizes, choose a size down.






Size: W13/M12

Length: **11.53**" | 293mm Width: **2.24**" | 57mm

- 1. Place heel against wall.
- 2. Measure length from wall to the tip of your big toe.
- 3. Choose the insole that fits the length of your foot. If the length of your foot is between sizes, choose a size down.





Size: M14

Length: **12.28**" | 312mm Width: **2.28**" | 58mm

- 1. Place heel against wall.
- 2. Measure length from wall to the tip of your big toe.
- 3. Choose the insole that fits the length of your foot. If the length of your foot is between sizes, choose a size down.





Size: M15

Length: **12.67**" | 322mm Width: **2.28**" | 58mm

- 1. Place heel against wall.
- 2. Measure length from wall to the tip of your big toe.
- 3. Choose the insole that fits the length of your foot. If the length of your foot is between sizes, choose a size down.





Size: M16

Length: **13.03**" | 331mm Width: **2.32**" | 59mm

- 1. Place heel against wall.
- 2. Measure length from wall to the tip of your big toe.
- 3. Choose the insole that fits the length of your foot. If the length of your foot is between sizes, choose a size down.

