Coneiak Polishing Arbors

	Set of Four 225490 225495 225490MM	Coneiaks ½-13 Thread %-11 Thread M16 Thread	40111	Set of Five Coneiak Minis 225650
	Tapered Co 225410 225415 225410MM	oneiak ½-13 Thread %-11 Thread M16 Thread		Tapered Coneiak Mini 225600
	Ball Nose C 225400 225405 225400MM	Coneiak ½-13 Thread %-11 Thread M16 Thread		Ball Nose Coneiak Mini 225615
	Slim Coneia 225440 225445 225440MM	ak ½-13 Thread %-11 Thread M16 Thread		Slim Coneiak Mini 225605
	Cylindrical 225450 225455 225450MM	Coneiak ½-13 Thread %-11 Thread M16 Thread		Cylindrical Coneiak Mini 225620
I	Hourglass (225430 225435 225430MM	Coneiak ½-13 Thread %-11 Thread M16 Thread		Double Ended Coneiak Mini 225610
	Grooved Co 225420 225425 225420MM	oneiak ½-13 Thread %-11 Thread M16 Thread		
	Double Dui 225460 225465	70meter ½-13 Thread %-11 Thread		

225460MM

M16 Thread

Material Polishing Guide

Material	Machine Speed	Hand Speed	Hand Pressure
Bio-Flex	Low	Slow	Lite
Cenplex	High	Fast	Normal to Hard
Co-Polymer	Low	Any	Lite to Normal
Durr-Flex	High or Low	Any	Normal
Durr-Plex	High	Fast	Normal to Hard
Kydex	High	Any	Normal
Polyethylene LD and LLD	High or Low	Any	Normal
Polypropylene	Low	Any	Normal
Pro-Flex	Low	Slow	Lite
Pro-Flex with Silicone	Low	Slow	Lite
Subortholen	High	Slow	Lite
Surlyn	High	Any	Normal to Hard
Thermoflex	Low	Slow	Lite
TPE	High	Slow	Lite

Use of Coneiak Minis

- For best results, drill attachment 2100S (large) or 2100R (small) should be used
- If using a rotary hand tool, the maximum speed should not exceed 5,000 RPMs
- Ensure that the shaft is at least halfway into chuck

Warranty

This product has a 6 month warranty against manufacturing defects. Polishing arbors wear with use. Wear is dependent upon the material being polished, the pressure applied by the user, and the length of use. Products returned with extensive wear will not be accepted for warranty credit.

Recommended for thermoplastic materials only. Warranty will be voided if used on thermoset materials (i.e. acrylic resins, laminations, etc.).

Please Note: Air bubbles may become visible after use but will not affect product performance.



www.fillauer.com

Fillauer LLC

2710 Amnicola Highway Chattanooga, TN 37406 423.624.0946 Fax 423.629.7936

© 2020 Fillauer LLC PM245/08-09/12-08-20