




Instructions - Model 750 Camber Axis Hinge



1. Prepare cast model and identify medial and lateral joint axis. Mark a vertical line through each axis perpendicular to the plantar surface of the cast.




2. Properly size the CAH joint and contour by shaping to the cast. Align to the marked ankle joint axis. Squared alignment is not required, but keep mechanical joint centers approximately equal in height.



3. Fit the precut pelite fabrication blanks to the hinge. Remove the center axis screw and replace with the black plaster screw and washer. Carefully thread screw through the center axis and pelite blank.


Note: Extreme valgus or varus deformities of the foot/ankle must receive special consideration during alignment and fabrication to avoid pressures from the uprights and fasteners of the CAH. These areas must be well padded utilizing the enclosed interface pads, or by adding additional build-ups as determined by the orthotist.




4. Drill 1/16" pilot holes at the joint axis on medial and lateral sides of plaster model. Align joints to the vertical lines, attaching hinges by tightening plaster screws until joints are flush with the cast surface.

Do not overtighten.

Fill any gaps with putty or plaster to prevent pulling plastic under the hinges.




5. Stretch an interface nylon over the model and vacuum form to standard procedures. After thermoplastic has cooled, grind the plastic over the center axis screw head and remove plaster screws. "Hot mark" the center of each attachment hole before removing the AFO shell. Mark and cut trim lines to release AFO from cast.




6. With the hinges removed, drill a #18 hole through "hot marks" centered at all clearance hole locations on the plastic. **Do not oversize clearance holes.**

Reinsert the hinges and mark trim lines for finishing at joint circumference before assembling AFO.




7. Insert hinges and assemble to AFO by securing #8-32 hinge attachment screws with threadlock. If required, careful peening of the #8-32 attachment screws will ensure permanent fixture in final assembly.



8. Place S.S. washer under the center axis screw head and torque the screw to 3-5 inch pounds.

Important:

- Apply threadlock to all screws during final assembly.
- Use #8-32 x 3/8" screw when assembling thicker materials.



9. Apply pelite or adhesive-backed Aliplast pads as a soft interface between joints and the skin.

Fabrication Notes:

- Do not overtighten the #8-32 hex head key screw (3-5 inch pounds).
- Motion Keys #5, #6, #7 require a light machine oil lubricant for proper movement once positioned in the slot.
- The Camber Axis Small key stop mechanism is reversed when compared to Medium and Large joint designs. Range of motion settings are not affected by this configuration.